

# Installation instructions for **UPSW-3-22MM**

- 1) **Remove grid and waste from waste body.**
- 2) **Place sealing washer in recess on top of waste body and offer assembly to the underside of the shower tray.**
- 3) **From the top side of the shower trap insert waste through waste hole into waste body.**
- 4) **Locate fixing key into waste. Position waste body in the final desired position and fully tighten.**
- 5) **Ensure all connection are fully cleaned before connection pipe work to outlet spigot.**
- 6) **Using 22mm pipe and Push fit fitting (not Supplied) connect outlet spigot to Drain Pump.**
- 7) **Remove grid and waste from waste body.**
- 8) **On Completion, a visual inspection of the waste outlet should be carried out to ensure that it is clean and free from debris.**
- 9) **Test the Installation**

**Note:**

**It should be possible to fully fit the shower waste to the tray before the tray is placed in final position.**

**Where a sealant is required, Dow Corning 794 or equivalent should be used.**