

CONTOUR Coving

Contour Coving is the pre-formed flooring profile with integrated tiling lip designed to significantly reduce installation and labour time.



When the floor former has been installed the coving can be cut to size and installed and the walls can be tiled, during one site visit, ready for the vinyl sheet flooring to be laid.



- Eliminates the need for installing separate coving and captile strips
- Rigid white ABS construction
- Supplied in 2 metre lengths. Can be cut to suit
- Significantly reduces on site labour
- Can be screwed to the wall and floor. Will help take up any minor undulations within a wall
- Easily modified to finish at a door architrave
- Creates a void between wall and coving which can be used to conceal pipework
- Can be used when plaster has not been finished to floor level



Supplied in 2 metre lengths. Can be cut on site to suit.



Coving creates a void, which can also be used for concealing plumbing



Eliminate the need for separate floor coving and captile strip.

The tiling lip will accept tiles or wallboards. The tiling lip is also used to secure the coving to the wall.

Reference 15CC2000

Technical Helpline:
0845 402 9924

Installation Guidelines



Using one coving profile as a guide, make a mark for the corner joint



Carefully cut away the outer extremity of the coving so that it will butt up tight in the corner



Both coving profiles should come together with a neatly cut edge



Screw the profile to the wall through the tiling lip



Pilot drill and screw to the floor former



Use silicone sealant at the corner joint to form a seal between the coving sections



Now tile your walls. Use silicone sealant to form a seal between Contour coving and the tiles



Contour Coving can be easily modified to finish at a door architrave. Mark the size required and cut to length



Measure back approximately 300mm from the architrave towards the corner and mark and cut out a rectangle



Using the cut-out section, cut diagonally from the bottom edge of the coving cut-out to approximately 20mm below the top corner



The cut-out section should taper towards the door architrave



Secure the bottom edge of your cut-out to floor. You should now have a tapered profile finishing at the door

Contour Coving

- Eliminate the need for separate coving & tiling strips
- Built in tiling lip
- Significantly reduces installation time